



CONNECTING CABLES



To connect cables

1. BNC/RCA/DC Connector.
2. 4PIN Aviation Connector.



Note

It is very important that you identify these ends before installing the cable so that you have the correct ends at the correct location.


INTRODUCTION

Feature

- * Metal-cased Vandal proof waterproof micro dome with fixed lens.
- * Low power consumption.
- * Easy installation on ceiling or wall, surface or flush mount.
- * 10 Infrared LEDs.
- * Audio optional.

Packing List


- * Camera
- * Instruction manual
- * Hex-key
- * Mounting screw



LOCH FÜR BOHRUNG IN BRIEFKASTEN-FRONT:

58 - 60 mm Durchmesser

HOW TO INSTALL



1. Use the attached hex key to loosen the hex head screw, then Counter clockwise rotation to open the lock ring .
2. Attach the mounting base to wall or ceiling.
3. Apply pressure to poly dome, and then move the ball to make the camera to the suitable position
4. Lock the dome camera.
5. Also can replace the transparent cover and the top cover.

SAFETY PRECAUTIONS

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received including interference that may cause undesired operation.

Note

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Correct Disposal of This Product



(Waste Electrical & Electronic Equipment) (Applicable in the European Union and other European countries with separate collection systems)
This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.
Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.